




SPARE PARTS LIST

POLE PRUNER/POLE SAWS


327 PT5S, 2012-01



ACCESSORIES

327 PT5S, 2012-01


Ref	Part no.	Description	Remark	Qty	Kit
1	537 04 07-10	ACCESSORY BAG		1	
2	501 69 17-01	COMBINATION WRENCH		1	1
3	502 21 58-01	L-NYCKEL		1	1
4	579 06 49-01	GREASE		1	
5	531 00 92-05	GREASE		1	
6	537 21 62-02	HARNESS	(USA)	1	
6	537 21 62-01	HARNESS		1	
7	575 84 22-58	BAR	10", 1/4" - 1,3 mm	1	
7	575 84 22-64	BAR	12", 1/4" - 1,3 mm	1	
8	501 84 40-58	SAW CHAIN	10", 1/4" - 1,3mm. 58DL	1	
8	501 84 40-64	SAW CHAIN	12", 1/4" - 1,3 mm. 64DL	1	
9	537 12 99-01	BAR GUARD		1	
10	505 20 43-01	HARNESS	Balance flex	1	



CARBURETOR

327 PT5S, 2012-01


Ref	Part no.	Description	Remark	Qty	Kit
1	503 28 34-01	CARBURETTOR	Zama C1Q-EL24	1	
2	503 48 05-01	SCREW		2	1
3	503 97 43-01	COVER		1	1
4	537 02 09-01	SHAFT ASSY		1	1
5	537 04 89-01	DIAPHRAGM		1	1
6	537 02 04-01	GASKET		1	1
7	503 48 01-01	SCREW		1	1
8	503 48 00-01	PIN RETAINING SCREW		1	1
9	537 37 03-01	VALVE		1	1
10	503 48 18-01	SCREW		1	1
11	537 02 10-01	SPRING		1	1
12	503 48 19-01	COLLAR		1	1
13	537 04 90-01	LEVER		1	1
14	503 47 90-01	SCREW		1	1
15	537 01 98-01	LEVER		1	1
16	503 47 89-01	COLLAR		1	1
17	503 66 59-01	LEVER		1	1
18	537 02 03-01	SPRING		1	1
19	503 47 97-01	VALVE		1	1
20	537 02 08-01	PLUG		1	1
21	503 48 08-01	SPRING		1	1
22	537 01 26-01	SPRING		1	1
23	537 01 25-01	BALL		1	1
24	503 53 57-01	STRAINER		1	1
25	537 12 78-01	SCREW		1	1
26	537 02 16-01	LIMITER CAP		1	1
27	503 97 40-01	WASHER		1	1
28	537 02 06-01	SCREW		1	1
29	537 02 16-01	LIMITER CAP		1	1
30	503 75 53-01	SCREW		1	1
31	537 01 97-01	SPRING		1	1
32	537 01 99-01	VALVE		1	1
33	503 47 92-01	SCREW		1	1
34	537 02 00-01	DIAPHRAGM PUMP		1	1
35	537 02 01-01	GASKET PUMP		1	1
36	537 01 96-01	SHAFT ASSY		1	1
37	537 02 02-01	COVER		1	1
38	503 48 11-01	PIECE		1	1
39	503 47 96-01	SCREW		1	1
40	537 02 07-01	SCREW		1	1
41	531 00 45-52	GASKET KIT		1	
42	531 00 45-53	SET		1	

G 327 PT5S
CLUTCH COVER & CRANK CASE

CLUTCH COVER & CRANK CASE

327 PT5S, 2012-01


Ref	Part no.	Description	Remark	Qty	Kit
1	537 30 96-01	COMPRESSION SLEEVE		1	
2	503 21 68-25	SCREW IHSCFT		2	1
3	537 04 12-09	CLUTCH COVER		1	
4	537 42 50-01	PROTECTIVE PLATE		1	3
5	503 20 03-16	SCREW IHSCFM	M5x16	1	3
6	537 07 36-01	SPRING		1	3
7	503 25 05-01	BALL BEARING		1	3
8	537 33 67-01	CIRCLIP		1	3
9	537 08 52-02	CRANKCASE		1	
10	537 06 69-01	GASKET CRANKCASE		1	
11	537 08 85-01	GASKET		1	9
12	537 06 68-01	INSERT CRANKCASE		1	9
13	503 20 03-16	SCREW IHSCFM		7	9
14	503 21 66-18	SCREW IHSCFT		2	9
15	503 21 77-16	SCREW IHSCFT		1	9
16	503 20 14-12	SCREW IHSCFMO	M5x12	1	9



COVER

327 PT5S, 2012-01


Ref	Part no.	Description	Remark	Qty	Kit
1	505 14 20-01	FILTER COVER		1	
2	505 14 22-01	COVER		1	
3	574 47 70-03	SCREW IHSCFMO	Captive screws	4	16
4	503 21 35-12	SCREW CCRPANT		2	
5	502 48 16-01	ARM PROTECTION		1	
6	544 84 81-02	HEAT PROTECTOR	Captive screws	1	
7	574 18 15-01	SCREW IHSCFTO	Captive screws	1	6
8	503 22 24-01	LOCKING NUT		1	
10	574 47 70-03	SCREW IHSCFMO	Captive screws	1	6
11	503 96 13-01	SCREW		1	
12	740 42 06-00	O-RING		1	
13	740 42 06-00	O-RING		1	
14	503 96 13-01	SCREW		1	
15	502 48 15-01	COVER		1	
16	505 14 18-02	CYLINDER COVER ASSY	Captive screws	1	
17	505 27 10-01	FILTER		1	
18	537 38 72-01	SNAP		2	
19	579 26 41-01	LOOP		1	
20	502 19 71-01	SQUARE NUT		1	19
21	725 23 81-51	SCREW EHHM		1	19
22	574 41 22-01	LOOP		1	19
23	574 41 21-01	SPACING BLOCK		1	19

L 327 PT5S
CRANK SHAFT

CRANKSHAFT

327 PT5S, 2012-01


Ref	Part no.	Description	Remark	Qty	Kit
1	503 85 24-74	CRANKSHAFT ASSY		1	
2	503 94 02-03	BEARING CAGE		1	1
3	503 94 05-01	CUP		1	1
4	503 71 22-01	BEARING		1	1
5	503 94 05-01	CUP		1	1
6	503 94 02-03	BEARING CAGE		1	1

K 327 PT5S
CYLINDER PISTON & MUFFLER

CYLINDER, PISTON & MUFFLER

327 PT5S, 2012-01

Ref	Part no.	Description	Remark	Qty	Kit
1	537 22 17-04	MUFFLER ASSY	Cat.	1	
2	537 22 18-01	SPARK ARRESTOR SCREEN		1	1
3	537 01 41-01	GASKET		1	
4	502 07 81-01	SCREW EHHFM		3	
5	537 08 51-03	CYLINDER	Ø=34mm	1	
6	503 20 07-35	SCREW IHSCFM		4	5
7	537 40 59-02	PISTON		1	5
8	537 40 62-01	PISTON RING		1	5,7
9	537 40 62-01	PISTON RING		1	5,7
10	737 44 08-00	CIRCLIP		1	5,7
11	503 71 22-01	BEARING		1	5,7
12	737 44 08-00	CIRCLIP		1	5,7




H 327 PT5S
FUEL TANK

FUEL TANK

327 PT5S, 2012-01

Ref	Part no.	Description	Remark	Qty	Kit
1	584 25 80-01	FUEL TANK ASSY		1	
2	581 75 62-01	FUEL HOSE		1	1
3	544 32 50-01	FUEL HOSE		2	1
4	503 73 58-01	BUSHING		1	1
5	504 02 24-01	HOSE CLAMP		1	1
6	503 44 32-01	FILTER		1	1
7	503 93 66-01	PRIMER HOUSING		1	
8	537 18 49-01	O-RING		1	1
9	544 88 97-02	TANK CAP		1	
10	503 91 10-01	SUSPENSION		4	
11	578 29 56-01	HOSE NIPPLE		1	1

J 327 PT5S
IGNITION SYSTEM & CLUTCH




IGNITION SYSTEM & CLUTCH

327 PT5S, 2012-01

Ref	Part no.	Description	Remark	Qty	Kit
1	502 49 36-01	SHORT CIRCUIT CABLE		1	
2	537 43 43-01	SPARK PLUG CAP		1	
3	503 23 51-09	SPARK PLUG		1	
4	544 12 70-01	IGNITION MODULE		1	
5	503 21 66-18	SCREW IHSCT		2	
6	537 23 75-01	CLUTCH DRUM ASSY		1	
7	503 84 29-02	SCREW		2	
8	537 04 67-02	WASHER		1	
9	537 03 22-01	CLUTCH ASSY		1	
10	503 84 28-01	CLUTCH SHOE		2	9
11	503 81 60-01	CLUTCH SPRING		1	9
12	537 04 68-02	WASHER		1	
13	731 71 16-51	HEXAGON NUT FLANGED		1	
14	537 24 96-02	FLYWHEEL		1	


E 327 PT5S
INTAKE




INTAKE

327 PT5S, 2012-01

Ref	Part no.	Description	Remark	Qty	Kit
1	505 27 10-01	FILTER		1	
2	503 91 09-01	INSULATION WALL		1	
3	503 94 26-01	INLET PIPE		1	
4	503 93 66-01	PRIMER HOUSING		1	
5	503 22 65-04	SQUARE NUT		2	
6	503 96 25-01	CHOKE CONTROL		1	
7	740 68 11-21	V-RING		1	
8	502 49 90-01	BRACKET		1	
9	503 21 75-50	SCREW IHSCFT		2	
10	503 21 77-16	SCREW IHSCFT		1	
11	503 28 34-01	CARBURETTOR	Zama C1Q-EL24	1	
12	503 49 71-01	GASKET		1	
13	503 20 03-25	SCREW IHSCFM		2	

A 327 PT5S
SAW HEAD


Ref	Part no.	Description	Remark	Qty	Kit
1	505 41 52-01	TANK CAP ASSY		1	37
2	525 61 31-01	COVER		1	37
3	510 04 43-01	OIL SCREEN		1	37
4	577 66 70-01	OIL TANK		1	37
5	525 49 06-01	OIL HOSE		1	37
6	735 31 11-00	CIRCLIP		2	37
7	574 82 98-01	COVER		1	37
8	738 21 99-04	BALL BEARING		3	37
9	525 49 04-01	SHAFT		1	37
10	575 35 56-01	GEAR WHEEL		1	37
11	738 21 00-04	BALL BEARING		1	37
12	525 48 16-01	KNOB		1	37
13	740 43 10-14	O-RING		1	37
14	503 24 09-11	NEEDLE ROLLER		1	37
15	540 05 79-01	PUMP PISTON		1	37
16	537 15 48-01	PUMP CYLINDER		1	37
17	576 39 59-01	FASTENER		1	37
18	501 81 92-01	SCREW		1	37
19	501 45 27-02	LOCKING NUT		1	37
20	501 45 41-01	NUT		1	37
21	523 85 37-01	GEAR HOUSING		1	37
22	576 83 10-01	SCREW IHSCM		1	37
23	573 92 58-01	SCREW ITXSCFT		3	37
24	525 49 07-01	BUSHING		1	37
25	574 40 47-01	RUBBER		1	37
26	525 48 14-01	COVER		1	37
27	503 22 00-07	HEXAGON NUT FLANGE		4	37
28	525 76 09-05	SCREW ITXSCM		1	37
29	525 75 51-04	SCREW ITXSCFM		1	37
30	574 86 50-01	SPUR SPROCKET		1	37
31	576 74 00-01	WASHER		1	37
32	731 71 16-51	HEXAGON NUT FLANGED		1	37
33	525 75 51-05	SCREW ITXSCFM		1	37
34	575 35 55-01	PINION		1	37
35	525 48 97-01	WORM GEAR		1	37
36	735 31 25-10	CIRCLIP		1	37
37	575 78 43-01	POLE SAW HEAD		1	

F 327 PT5S
STARTER

STARTER

327 PT5S, 2012-01

Ref	Part no.	Description	Remark	Qty	Kit
1	503 87 33-05	STARTER PAWL BRIDGE		1	
2	735 31 08-20	E-CLIP		2	1
3	503 87 36-01	SPRING		1	1
4	503 87 35-02	STARTER PAWL		2	1
5	505 19 83-01	STARTER ASSY		1	
6	503 21 88-76	SCREW IHSCFT		1	5
7	537 33 23-03	STARTER PULLEY		1	5
9	505 30 51-25	STARTER CORD		1	5
10	537 00 84-01	STARTER HANDLE		1	5
11	505 14 13-01	STARTER ASSY		1	5
13	503 20 03-16	SCREW IHSCFM	M5x16	3	
15	503 21 75-16	SCREW IHSCFT		2	
16	503 20 14-12	SCREW IHSCFMO	M5x12	1	
17	537 17 45-01	HANDLE		1	
18	577 41 60-01	BRACKET ASSY		1	
20	503 21 53-16	SCREW ITXSCM		1	
21	537 32 24-12	LABEL		1	
22	537 32 50-03	STARTER PULLEY		1	5
23	503 85 99-01	RECOIL SPRING		1	5




TELESCOPE POLE

327 PT5S, 2012-01

Ref	Part no.	Description	Remark	Qty	Kit
1	576 92 60-01	BEARING SLEEVE		1	
2	576 92 58-01	TUBE		1	
3	576 92 56-01	DRIVE SHAFT		1	
4	576 92 55-01	FRAME TUBE		1	
5	576 92 57-01	TUBE		1	
6	510 09 61-01	NUT		1	
7	522 74 26-01	RING		1	
8	510 09 60-01	CLAMPING SLEEVE		1	
9	731 23 14-01	HEXAGON NUT		5	
10	525 75 51-02	SCREW ITXSCFM		5	
11	530 01 60-64	SCREW		1	4
13	537 09 45-01	SLIDING SHOE		5	2
14	735 31 28-10	CIRCLIP		1	2
15	574 61 89-01	ADAPTER		1	
16	510 09 73-01	BEARING HOUSING		3	
17	510 09 47-01	BEARING HOUSING		3	
18	738 21 01-02	BALL BEARING		6	
19	510 09 52-01	SPRING		3	
20	574 61 91-01	ADAPTER		1	
21	510 09 59-01	GUIDE BUSHING		1	
22	522 59 70-01	CLAMPING SLEEVE		1	
23	576 22 12-01	RIVET		4	2
24	579 26 40-01	LOOP		1	
25	502 19 71-01	SQUARE NUT		1	24
26	725 23 81-51	SCREW EHHM		1	24
27	522 72 31-01	LOOP		1	
28	522 72 33-01	SPACING BLOCK		1	24
29	502 20 38-01	KNOB		1	24
not shown	510 11 25-01	CIRCLIP		1	

C 327 PT5S THROTTLE CONTROLS



THROTTLE CONTROLS

327 PT5S, 2012-01

Ref	Part no.	Description	Remark	Qty	Kit
1	544 14 36-04	CONTROL		1	
2	537 41 90-01	SWITCH		1	1
3	503 21 66-18	SCREW IHSC T		5	1
4	503 96 14-01	VIBRATION ABSORBER		1	
5	503 91 81-01	THROTTLE LEVER		1	
6	503 87 80-01	THROTTLE LOCKOUT		1	
7	544 10 02-02	HANDLE HALF RIGHT		1	1
8	544 10 08-01	RECOIL SPRING		1	1
9	503 87 79-03	THROTTLE TRIGGER		1	1
10	544 10 17-02	RUBBER DAMPER		1	1
11	503 20 03-20	SCREW IHSCFM		1	
12	544 10 03-02	HANDLE HALF LEFT		1	1
13	544 10 17-02	RUBBER DAMPER		1	1
14	731 23 14-01	HEXAGON NUT		1	1
15	544 11 21-01	RETAINER		1	1
16	502 65 13-01	WIRING		1	1
17	502 53 16-01	SHORT CIRCUIT CABLE		1	1,16
18	544 17 17-03	THROTTLE WIRE ASSY		1	1,16
19	523 06 26-01	TRIGGER	GUARD	1	
20	503 22 65-01	SQUARE NUT		1	
21	503 20 16-02	SCREW IHSCFM		1	